




ASSEMBLY MANUAL

RTW RISER SHELF & POWER PANEL

Item Numbers 8467-8474, 8328







PARTS AND HARDWARE	QUANTITY
End Supports	2
Cross Bars	2
End Support Mount	2
End Support Cover	2
Laminate Shelf	1
Tek Screws	8
Wood Screws	14
Kep Nut	12
1/4-20 Screws- 1/2"	8
Allen Wrench	1
Other Items Needed (not included)	
Phillips head drill or screwdriver	
Tape Measure	
	•

- Attach Cross Bars to End Supports with nuts and bolts as shown.
- Invert laminate shelf and position frame from step #1 on top with a 3/8" overhang on left and right sides and back. Front will have a 3 3/8" overhang.
- Use wood screws to secure frame to shelf. Set aside until step 5.
- Slide End Support Mounts over right and left edges of worksurface with studs facing up.
- Flip shelf assembly from step #3. Position holes in bottom of End Supports over End Support Mounts.
 Secure nuts onto studs to hold Riser Shelf to end support mounts.
- 6. Slide Riser Shelf toward rear of bench. End Supports should be approximately 3/4" from rear edge of bench.
- 7. Secure Riser Shelf to underside of bench using wood screws through end support mounts.
- Install End Support Covers onto inside of end supports with tek screws. If installing Power Panel (Item #8328), do so on inside left of Riser Shelf, in place of the left end support cover.



Production Basics, Inc. Massachusetts, USA 800.318.2770 617.926.8100 Fax: 617.926.8010 www.pbasics.com 1303A846